
AROUND
USER GUIDE

CH6200



FURSYS

구입해 주셔서 감사합니다.
제품 사용전 가이드를
충분히 숙지하시기바랍니다.

Thank you for your purchase.
Please be familiar with the guide
before using the product.


CONTENTS

1. PRODUCT INFORMATOIN — 14

2. MANUAL — 15

3. WARNINGS — 19

AROUND



❶ Height of seat

❷ Backrest tilting

❸ Strength of tilting

❹ Depth of seat

❺ Armrest


❻ Neckrest/Lumbar support

PRODUCT INFORMATION

MODEL	AROUND hedrest Chair
COLOR	2H3B / 2H4B / 2H6B / 2H7LB


MANUAL

❶ Adjusting the height of seat




- When elevating the height of seat, lift up the lever then release it at the height desired.
- When lowering the height of seat, sit on the center of the chair then lift up the lever, release it at the desired height

❷ Adjusting the backrest tilting




- Adjust the reclining angle of the backrest by turning the left lever without leaning gainst the backrest.
- Turn the lever counterclockwise to decrease the angle.
- Return the lever to lean all the way back.

❸ Adjusting the Strength of tilting



- To adjust intensity of reclining, pull outthe lever on the right side. Turn anticlockwise to increase the intensity and clockwise to decrease.

❹ Adjusting the depth of seat




- Push the button located on lower left side of seat then pull out the front side of seat thenyou will be able to use 5-Step depth adjusting function for your convenience.
  (Whenadjusting the depth of seat, please do it when standing up.)

❺ Adjusting the armrest

- **Armrest height**

  Push the button located on the lower sideof left/right arm pad and adjust the height



- **Armrest angle**

- To adjust angle of armpad, grab thearmpad and move it to the direction you want it to be.

  * A model whose code includes 'A'



❻ Adjusting Neckrest /Lumbar support

- **Headrest height**


  Grab the neckrest using both hands then fix it at the desired height.

  * A model whose code includes 'H'



- **Lumbar support**

  You can adjust the lumbar both up anddown to fit your body



* CH6200 - All models
  T40 - A model whose code includes 'L'

PRECAUTIONS

- Do not stand on the chair since you may get injured due to the movement of casters.

- Do not sit on the edge of chair for the possible overturn.

- Do not use the chaor for the other that it originally meant to be.

- Please be advised that the warranted weight capacity of the chair is 113kgs or less.

- If you put excessive impact on the chair while tilted, it may be damaged.

- If you sit astraddle on seat or backrest, you may get injured due to the possible overturn of chair.

- Do not astraddle on armrest to prevent possible slipping.

- Do not press the backrest while someone is seated on the chair.

- Do not sit on the chair when someone is under the chair.

- Do not push the chair when someone is seated.

- Do not push the chair when someone is seated, the person mat get injured.

- Please do not use each chair more than two person.

- When you sit on the chair without putting your shoes on, make sure your toes will be safe from the movement of casters.

- Do not sit in a position where your face the headrest of the chair for possible overturn.

- Do not put or insert your finger in to ant part of the chair.

- Do not out your finger into the gap of the chair.

- Do not use the chair in a position like you use the chair with maximun tilted and put your legs on the desk or any other objects.

- When seating, please do not tilt your body either forward or left/right excessively.

- The chair may get overturned when you rotate the chair while putting your legs on the seat.

- Do not ues the chair for exercise such as push-ups.

- Do not lean yur hands or body against the chair when standing up since it may cause possible injury due to the unexpeated movement of casters.

- Do not throw the chair.

- Do not kick the chair.

- Do not astraddle on tablet of the chair since it may be broken.

- Do not walk across the chair.

- Do not put your legs under the base of chair and tilt your body forward since it may cause possible overturn of the chair.

- Please get full knowledge for usage of the chair beforhand for more proper use.

- Please note that the contact surface of the mesh back plate may be damaged by the sharp edge of the table.

- We do not apply any warranty for any poddible inhuries, dangers and damages caoused by neglect of the above warnings.

FURSYS

주소	서울 송파구 오금로 45-1 퍼시스빌딩 Fursys Bldg 45-1, Ogum-Dong, Songpa-Gu
A/S센터	1588-1244
제품문의	02)443-9999
홈페이지	WWW.fursys.com